



inhibit PWM when there is no magnet.
 Use RV3 and R4 to determine which sensor voltage means 'no magnet'
 Note: -15V is unregulated, hence RV3

L = 23 m 0.5 mm magnet wire on M10x120 hex bolt

Sheet: /	
File: zweefmagneet_opamps.kicad_sch	
Title:	
Size: A4	Date:
KiCad E.D.A. kicad (6.0.5-0)	Rev: Id: 1/1